


# OLSEM WANEM BLONG KLINIM OL SAWYER WOTA FILTA

Beswei blong klinim filta evridei, mo klinim lid blong filta mo ol baket wetem sop no losavel.



## KLINIM WETEM SIRINJ


**STEP 1**  
Holem haf lita klin wota long baket.



**STEP 2**  
Fulumap sirinj wetem klin wota.




**STEP 3**  
Meksua se baket i emti. Lego filta i joen wetem kaoju, mo pusum wota blong sirinj i go insaed long filta. Mekem strong, mo mekem bakegen tu taem. Sakemaot wota ia.




Mekem bakegen gogo i klin

## OL NARAFALA SAMTING FASIN BLONG KLINIM FILTA TAEM FILTA I NO RON GUD TAEM YU KLINIM FINIS.

**STEP 1**  
Karemaot waet lid mo karemaot filta long kaoju.



**STEP 2**  
Fulumap sirinj mo pusum wota long fored blong filta. Hemia i muvum eni doti. Gohed blong pusum wota long tufala en olsem gogo filta i klin gud.



Repitim bak proces mo tanem apsaet taon olsem web i stap pija.


**STAP KLIN GUD:** Sawyer i talem se i gud blong yu klinim gud filta blong yu klinim gud filta blong yu wanwan taem. Blong mekem i klin olsem, yu mas wasem filta weten wan standed solution blong blij (2 spun nomo long one lita) blong clean wota. Pusum wota ia long filta blong klinim. Letem i drae fulwan long wan ples we i no hot tumas. Afta yu save yusum.

**OL DOTI I BLOKEM FILTA:** Sipos filta blong yu i no ron gud afta we yu bin klinim, putum long wan dis hotwota (no mas hot moa bitim wanem yu save putum han blong yu long hem). Lego i stap wan aoa. Afta klinim bakegen wetem hotwota we i klin, RIMEMBA mas pusum STRONG! Taem yu pusum sirinj, yu no mekem sloslo, from samting ia bae i klinim smol haf blong filta nomo. Taem yu mekem strong i pusumaot evri doti we oli stap insaed.


**CALCIUM I FULAP LONG FILTA:** Sipos yu bin mekem ol narafala samting finis blong klinim be filta i no ron gud, maet calcium i kam fulap long hem. Putum filta i stap long wan dis we i fulap wetem viniga long 1/2 aoa, mo afta yu klinim wetem klin hotwota (no mas hot moa bitim wanem yu save putum han blong yu long hem). Mekem bakegen gogo i ron gud bakegen—maet yu mas mekem fulap taem.

## KLINIM WETEM BLU KAPLING (plastic blong skru)


**STEP 1**  
Faenem wan plastik we i save joen wetem blu kapling. Wasem plastik mo fulumap wetem klin wota we i bin pas long filta finis.




**STEP 2**  
Skruiem blu kapling long en blong filta.



**STEP 3**  
Meksua se baket i emti. Tekem filta we yu putum kapling long hem, mo skruiem long plastik.



**STEP 4**  
Presem plastik strong mo mekem bakegen mo bakegen gogo filta i klin. Sakemaot wota ia.



Mekem bakegen gogo i klin